

Rim Tape

Usage



1. Start at the valve hole and cover it as you move around the circumference.
2. Fit tightly and evenly into the rim bed
3. Trim off neatly.



RT-01(Clear)

2pcs/ box
boxes/ CTN.

Material: polyolefin film (PO)
Length: 10m
Total thickness: 140um
Film thickness: 100um

Cu'ft:
N.W.:
G.W.:



RT-02(Black)

2pcs/ box
boxes/ CTN.

Material: polyester film (PET)
Length: 10m
Total thickness: 90um
Film thickness: 50um

Cu'ft:
N.W.:
G.W.:



RT-03(Blue)

2pcs/ box
boxes/ CTN.

Material: Monoaxially Oriented
Polypropylene Film (MOPP)
Length: 10m
Total thickness: 125um
Film thickness: 85um

Cu'ft:
N.W.:
G.W.:



RT-04(Black)

2pcs/ box
boxes/ CTN.

Material: polyimide film (PI)
Length: 10m
Total thickness: 116um
Film thickness: 75um

Cu'ft:
N.W.:
G.W.: