Outer width

Fixing Plate

1000mm top curtain

Friction-proof Curtain

Inner height

Outer height

Fixing Plate

Yellow Caution Paint

Inner width

Back Plate

Inner height

Outer Height

Friction-proof Curtain

Floor

250

Outside Floor

Inner width

300

Fixing bolt

Fixing Plate

Friction-proof Curtain

250

Installation Manual:

1. Check the wall opening: The outside wall surface should be plain.
2. The outside floor and inside floor should be finished.
3. Measure the total width and mark vertical line on the wall.
4. Measure the total height and mark horizontal line on the wall.
5. Make screw holes on the back steel support of dock seal column.
6. Install the fixing angle plate onto back steel support with screws.
7. Set up side columns along the side vertical line and fix with expansion bolts onto wall.
8. Lift up top column along with top horizontal line and fix with expansion bolt onto wall.
9. Check verticality and horizontality.
10 Finish.

Unit (mm)		Project:		Shanghai Kenvo Door Co.,Ltd	
		Product: Sponge Insulated Dock Seal	Drawing:	FST	
			Check:		
			Drawing No.		