

PT pump & spare parts Catalogue

Engine Model: Cummins NT KT M11

[SHIYAN XIANGREN INDUSTRY & TRADE CO.,LTD](http://www.shiyanxiangren.com)

www.syxrgs.com www.syxrgs.com.cn www.magdiesel.com

	P/N	Description
1	2888812	PT fuel pump
2	3042115	PT fuel pump
3	3045281	PT fuel pump
4	3058214	PT fuel pump
5	3060945	PT fuel pump
6	3060947	PT fuel pump
7	3060948	PT fuel pump
8	3060949	PT fuel pump
9	3060973	PT fuel pump
10	3064676	PT fuel pump
11	3065756	PT fuel pump
12	3065765	PT fuel pump
13	3068708	PT fuel pump
14	3070825	PT fuel pump
15	3074666	PT fuel pump
16	3074672	PT fuel pump
17	3074763	PT fuel pump
18	3074835	PT fuel pump
19	3074843	PT fuel pump
20	3080571	PT fuel pump
21	3080584	PT fuel pump
22	3081020	PT fuel pump
23	3086397	PT fuel pump
24	3086405	PT fuel pump
25	3088673	PT fuel pump
26	3088681	PT fuel pump
27	3096205	PT fuel pump
28	3096276	PT fuel pump
29	3098495	PT fuel pump
30	3165355	PT fuel pump
31	3165356	PT fuel pump
32	3165359	PT fuel pump
33	3165385	PT fuel pump
34	3165399	PT fuel pump
35	3165400	PT fuel pump
36	3165401	PT fuel pump
37	3165437	PT fuel pump

38	3165457	PT fuel pump
39	3165468	PT fuel pump
40	3165621	PT fuel pump
41	3165655	PT fuel pump
42	3165660	PT fuel pump
43	3165661	PT fuel pump
44	3165692	PT fuel pump
45	3165705	PT fuel pump
46	3165770	PT fuel pump
47	3165797	PT fuel pump
48	3201457	PT fuel pump
49	3201660	PT fuel pump
50	3201676	PT fuel pump
51	3201870	PT fuel pump
52	3201909	PT fuel pump
53	3202040	PT fuel pump
54	3202268	PT fuel pump
55	3202303	PT fuel pump
56	3261946	PT fuel pump
57	3262030	PT fuel pump
58	3262033	PT fuel pump
59	3262175	PT fuel pump
60	3262778	PT fuel pump
61	3263592	PT fuel pump
62	3263593	PT fuel pump
63	3264000	PT fuel pump
64	3264282	PT fuel pump
65	3264283	PT fuel pump
66	3264582	PT fuel pump
67	3264686	PT fuel pump
68	3264705	PT fuel pump
69	3266659	PT fuel pump
70	3267978	PT fuel pump
71	3278682	PT fuel pump
72	3279768	PT fuel pump
73	3328951	PT fuel pump
74	3347530	PT fuel pump
75	3347539	PT fuel pump
76	3400953	PT fuel pump
77	3401428	PT fuel pump
78	3410180	PT fuel pump
79	3417792	PT fuel pump
80	3417810	PT fuel pump
81	3419103	PT fuel pump
82	3419215	PT fuel pump

83	3419216	PT fuel pump
84	3419217	PT fuel pump
85	3419260	PT fuel pump
86	3419261	PT fuel pump
87	3419406	PT fuel pump
88	3419417	PT fuel pump
89	3419433	PT fuel pump
90	3419453	PT fuel pump
91	3419462	PT fuel pump
92	3419463	PT fuel pump
93	3419466	PT fuel pump
94	3419467	PT fuel pump
95	3419468	PT fuel pump
96	3630673	PT fuel pump
97	3630674	PT fuel pump
98	3631721	PT fuel pump
99	3631724	PT fuel pump
100	3631871	PT fuel pump
101	3632507	PT fuel pump
102	3632513	PT fuel pump
103	3632523	PT fuel pump
104	3632623	PT fuel pump
105	3632711	PT fuel pump
106	3638567	PT fuel pump
107	3646907	PT fuel pump
108	3655015	PT fuel pump
109	3655041	PT fuel pump
110	3655044	PT fuel pump
111	3655045	PT fuel pump
112	3655100	PT fuel pump
113	3655101	PT fuel pump
114	3655104	PT fuel pump
115	3655116	PT fuel pump
116	3655169	PT fuel pump
117	3655213	PT fuel pump
118	3655214	PT fuel pump
119	3655215	PT fuel pump
120	3655223	PT fuel pump
121	3655233	PT fuel pump
122	3655280	PT fuel pump
123	3655308	PT fuel pump
124	3655323	PT fuel pump
125	3655337	PT fuel pump
126	3655379	PT fuel pump
127	3655406	PT fuel pump

128	3655434	PT fuel pump
129	3655562	PT fuel pump
130	3655631	PT fuel pump
131	3655642	PT fuel pump
132	3655644	PT fuel pump
133	3655647	PT fuel pump
134	3655652	PT fuel pump
135	3655654	PT fuel pump
136	3655758	PT fuel pump
137	3655884	PT fuel pump
138	3655889	PT fuel pump
139	3655898	PT fuel pump
140	3655908	PT fuel pump
141	3655949	PT fuel pump
142	3655952	PT fuel pump
143	3655965	PT fuel pump
144	3655993	PT fuel pump
145	3655994	PT fuel pump
146	3655996	PT fuel pump
147	3899014	PT fuel pump
148	4009414	PT fuel pump
149	4022888	PT fuel pump
150	4060178	PT fuel pump
151	4060190	PT fuel pump
152	4060237	PT fuel pump
153	4060272	PT fuel pump
154	4060286	PT fuel pump
155	4060307	PT fuel pump
156	4060797	PT fuel pump
157	4060852	PT fuel pump
158	4060875	PT fuel pump
159	4060904	PT fuel pump
160	4060912	PT fuel pump
161	4060914	PT fuel pump
162	4060915	PT fuel pump
163	4060960	PT fuel pump
164	4060963	PT fuel pump
165	4060965	PT fuel pump
166	4060967	PT fuel pump
167	4060981	PT fuel pump
168	4060985	PT fuel pump
169	4061121	PT fuel pump
170	4061145	PT fuel pump
171	4061182	PT fuel pump
172	4061206	PT fuel pump

173	4061226	PT fuel pump
174	4061228	PT fuel pump
175	4061417	PT fuel pump
176	4061438	PT fuel pump
177	4082713	PT fuel pump
178	4083021	PT fuel pump
179	4095088	PT fuel pump
180	4295862	PT fuel pump
181	4913582	PT fuel pump
182	4913594	PT fuel pump
183	4915011	PT fuel pump
184	4915037	PT fuel pump
185	4915406	PT fuel pump
186	4915408	PT fuel pump
187	4915409	PT fuel pump
188	4915410	PT fuel pump
189	4915411	PT fuel pump
190	4915417	PT fuel pump
191	4915427	PT fuel pump
192	4915428	PT fuel pump
193	4915428	PT fuel pump
194	4915429	PT fuel pump
195	4915430	PT fuel pump
196	4915431	PT fuel pump
197	4915440	PT fuel pump
198	4915445	PT fuel pump
199	4915446	PT fuel pump
200	4915447	PT fuel pump
201	4915471	PT fuel pump
202	4915472	PT fuel pump
203	4915474	PT fuel pump
204	4915486	PT fuel pump
205	4922620	PT fuel pump
206	4951350	PT fuel pump
207	4951351	PT fuel pump
208	4951352	PT fuel pump
209	4951353	PT fuel pump
210	4951354	PT fuel pump
211	4951355	PT fuel pump
212	4951356	PT fuel pump
213	4951357	PT fuel pump
214	4951358	PT fuel pump
215	4951360	PT fuel pump
216	4951361	PT fuel pump
217	4951362	PT fuel pump

218	4951363	PT fuel pump
219	4951390	PT fuel pump
220	4951398	PT fuel pump
221	4951403	PT fuel pump
222	4951407	PT fuel pump
223	4951408	PT fuel pump
224	4951410	PT fuel pump
225	4951412	PT fuel pump
226	4951415	PT fuel pump
227	4951418	PT fuel pump
228	4951419	PT fuel pump
229	4951420	PT fuel pump
230	4951424	PT fuel pump
231	4951426	PT fuel pump
232	4951437	PT fuel pump
233	4951438	PT fuel pump
234	4951440	PT fuel pump
235	4951441	PT fuel pump
236	4951443	PT fuel pump
237	4951450	PT fuel pump
238	4951451	PT fuel pump
239	4951452	PT fuel pump
240	4951454	PT fuel pump
241	4951457	PT fuel pump
242	4951459	PT fuel pump
243	4951461	PT fuel pump
244	4951462	PT fuel pump
245	4951463	PT fuel pump
246	4951465	PT fuel pump
247	4951477	PT fuel pump
248	4951493	PT fuel pump
249	4951495	PT fuel pump
250	4951499	PT fuel pump
251	4951501	PT fuel pump
252	4951503	PT fuel pump
253	4951507	PT fuel pump
254	4951517	PT fuel pump
255	4951519	PT fuel pump
256	4951523	PT fuel pump
257	4951530	PT fuel pump
258	4951531	PT fuel pump
259	4951537	PT fuel pump
260	4951544	PT fuel pump
261	4999451	PT fuel pump
262	4999453	PT fuel pump

263	4999454	PT fuel pump
264	4999456	PT fuel pump
265	4999463	PT fuel pump
266	4999465	PT fuel pump
267	4999466	PT fuel pump
268	4999467	PT fuel pump
269	4999468	PT fuel pump
270	4999469	PT fuel pump
271	4999470	PT fuel pump
272	69765	PT fuel pump
273	75530	PT fuel pump
274	76656	PT fuel pump
275	3419429	PT fuel pump
276	3419458	PT fuel pump
277	3655583	PT fuel pump
278	4060947	PT fuel pump
279	4060961	PT fuel pump
280	3638569	PT fuel pump
281	4951502	PT fuel pump
282	71925	PT fuel pump
283	3076945	PT fuel pump
284	79464	PT fuel pump
285	4951427	PT fuel pump
286	4083129	PT fuel pump
287	3646708	PT fuel pump
288	4951399	PT fuel pump
289	3013725	PT injector
290	3016675	PT injector
291	3016676	PT injector
292	3018223	PT injector
293	3018352	PT injector
294	3018566	PT injector
295	3018568	PT injector
296	3018816	PT injector
297	3018833	PT injector
298	3018854	PT injector
299	3022197	PT injector
300	3046281	PT injector
301	3046315	PT injector
302	3047968	PT injector
303	3047973	PT injector
304	3047976	PT injector
305	3047991	PT injector
306	3047992	PT injector
307	3052255	PT injector

308	3053124	PT injector
309	3053126	PT injector
310	3054071	PT injector
311	3054216	PT injector
312	3054217	PT injector
313	3054218	PT injector
314	3054219	PT injector
315	3054220	PT injector
316	3054226	PT injector
317	3054228	PT injector
318	3054231	PT injector
319	3054233	PT injector
320	3054254	PT injector
321	3054255	PT injector
322	3068825	PT injector
323	3071492	PT injector
324	3071497	PT injector
325	3076132	PT injector
326	3076134	PT injector
327	3076700	PT injector
328	3076702	PT injector
329	3076703	PT injector
330	3076704	PT injector
331	3077714	PT injector
332	3077715	PT injector
333	3077760	PT injector
334	3079946	PT injector
335	3079947	PT injector
336	3087587	PT injector
337	3087648	PT injector
338	3095773	PT injector
339	3096538	PT injector
340	3279661	PT injector
341	3279664	PT injector
342	3349860	PT injector
343	3349861	PT injector
344	3406604	PT injector
345	3411821	PT injector
346	3609849	PT injector
347	3609962	PT injector
348	3609968	PT injector
349	3627922	PT injector
350	4912080	PT injector
351	4913770	PT injector
352	4914177	PT injector

353	4914228	PT injector
354	4914308	PT injector
355	4914325	PT injector
356	4914328	PT injector
357	4914452	PT injector
358	4914453	PT injector
359	4914458	PT injector
360	4914505	PT injector
361	4914537	PT injector
362	4915382	PT injector
363	4999492	PT injector
364	3054250	PT injector
365	3076130	PT injector
366	4296423	PT injector
367	4914555	PT injector
368	3071494	PT injector
369	3000798	oil cup
370	3003929	oil cup
371	3003930	oil cup
372	3003931	oil cup
373	3004054	oil cup
374	3006540	oil cup
375	3006543	oil cup
376	3006545	oil cup
377	3010511	oil cup
378	3012535	oil cup
379	3012536	oil cup
380	3012537	oil cup
381	3012538	oil cup
382	3018813	oil cup
383	3018814	oil cup
384	3018861	oil cup
385	3018862	oil cup
386	3018863	oil cup
387	3022154	oil cup
388	3023556	oil cup
389	3024148	oil cup
390	3047503	oil cup
391	3052229	oil cup
392	3052630	oil cup
393	3053742	oil cup
394	3064252	oil cup
395	3069764	oil cup
396	3071046	oil cup
397	3073753	oil cup

398	3095024	oil cup
399	3202078	oil cup
400	3278446	oil cup
401	3279637	oil cup
402	4914616A	oil cup
403	3001314	oil cup
404	3003932	oil cup
405	3003933	oil cup
406	3005963	oil cup
407	3042713	oil cup
408	3077716	oil cup
409	3084895	oil cup
410	3279720	oil cup
411	3609933	oil cup
412	3005963G1	oil cup
413	3609964	oil cup
414	3028068	oil cup
415	3069703	oil cup
416	3069717	oil cup
417	3070617	oil cup
418	3071564	oil cup
419	3071648	oil cup
420	3073570	oil cup
421	3073573	oil cup
422	3073575	oil cup
423	3074253	oil cup
424	3074254	oil cup
425	3074255	oil cup
426	3087649	oil cup
427	3406605	oil cup
428	3411822	oil cup
429	3609797	oil cup
430	3609841	oil cup
431	3003920	oil cup
432	3062094	oil cup
433	3052522	oil cup
434	3070615	oil cup
435	3279747	oil cup
436	4914454	oil cup
437	3069756	oil cup
438	3349862	oil cup
439	3035738	HVT shutoff valve
440	3056564	STC control valve
441	3059314	HVT shutoff valve
442	3063022	STC control valve

443	3066463	viscosity sensor
444	3071599	STC control valve
445	3076334	STC control valve
446	3086455	STC control valve
447	3090732	STC control valve
448	3096081	STC control valve
449	4296433	HVT shutoff valve
450	3060605	Barrel & Plunger
451	3076339	STC control valve
452	3060609	STC control valve
453	3103538	oil control valve
454	129886	fuel shutoff valve body
455	3010092	fuel pump housing
456	3010810	governor plunger
457	3013643	valve shutoff
458	3015522	check valve
459	3015595	VS governor plunger
460	3015597	throttle shaft
461	3015665	tachometer drive assy
462	3015750	VS governor housing
463	3016021	VS governor housing
464	3016609	gear and shaft
465	3016610	gear and shaft
466	3016611	gear and shaft
467	3017993	shutoff valve
468	3017996	carrier weight
469	3018324	Barrel & Plunger
470	3018453	valve shutoff
471	3019613	gear and shaft
472	3019616	gear and shaft
473	3019617	gear and shaft
474	3020523	Cover & Bsh Assy VS Gov
475	3021420	solenoid
476	3021977	spring cover
477	3024989	upper weight assembly
478	3024991	lower weight assembly
479	3028347	barrel plug assembly
480	3028368	cover and bushing assy
481	3028372	main drive assembly
482	3030267	pump front cover assy
483	3030274	fuel pump front cover
484	3031298	AFC assembly
485	3034209	fuel pump gear assy
486	3034211	fuel pump gear assy(3034241)
487	3034214	fuel pump gear assy(1.25)

488	3034217	gear fuel pump assy(3034243)
489	3034219	fuel pump gear assy
490	3034221	fuel pump gear assy
491	3034222	fuel pump gear assy
492	3034229	fuel pump gear assy
493	3034236	fuel pump gear assy
494	3035342	shutoff valve assembly
495	3035344	shutoff valve assembly
496	3035346	shutoff valve assembly
497	3035362	shutoff valve assembly(3035344)
498	3035684	fuel pump body
499	3035694	fuel pump housing
500	3037292	barrel
501	3037997	shutoff valve assembly(3026610)
502	3039367	fuel pump body
503	3040760	governor plunger
504	3041494	AFC assembly
505	3043000	shutoff valve assembly
506	3043036	fuel pump body
507	3047963	Barrel & Plunger
508	3047964	barrel
509	3048229	fuel pump body
510	3048230	fuel pump body
511	3048241	fuel pump body assy
512	3049996	Barrel & Plunger
513	3052222	barrel/plunger assembly
514	3052254	Barrel & Plunger
515	3052864	pump front cover assy
516	3053215	shutoff valve assembly (big hole)
517	3053456	shutoff valve assembly (big hole)
518	3054609	solenoid
519	3054610	solenoid
520	3058505	fuel pump body
521	3058944	AFC barrel
522	3059603	Air Fuel Control Assembly
523	3069718	
524	3070751	AFC assembly
525	3074225	AFC barrel & plunger
526	3075381	hyd var timing tappet
527	3075383	hyd var timing tappet
528	3076125	barrel & plunger
529	3076126	barrel & plunger
530	3076127	barrel & plunger
531	3076341	STC control valve(M11)
532	3077526	barrel & plunger

533	3077526	barrel & plunger
534	3079945	barrel & plunger(N-STC)
535	3084892	barrel & plunger
536	3096079	fuel filter
537	3096857	shutoff valve assembly
538	3096859	shutoff valve assembly
539	3279602	fuel pump body
540	3279798	AFC assembly
541	3348327	shutoff valve assembly(big hole)
542	3408324	etr fuel control atuator(3063504)
543	3408326	etr fuel control atuator
544	3408328	etr fuel control atuator(3063510)
545	3419476	AFC barrel & plunger
546	3627868	barrel & plunger(K)
547	AR12110	fuel pump & mtg damper
548	AR12111	fuel pump & mtg damper
549	AR12112	fuel pump & mtg damper
550	AR2854	FP OUTLET FITTING
551	AR3034	THROTTLE LEVER
552	AR3036	THROTTLE LEVER
553	AR40130	governor plunger
554	AR40230	VS governor plunger
555	AR40240	VS governor plunger
556	AR41010	throttle shaft
557	AR41012	throttle shaft
558	AR41013	throttle shaft
559	AR41014	throttle shaft
560	AR41070	throttle shaft
561	AR41071	throttle shaft
562	AR475	FP INLET FITTING
563	AR476	FP INLET FITTING
564	AR6573	THROTTLE LEVER
565	BM36360	Fp Outlet Fitting(3030863)
566	BM73106	VS THROTTLE LEVER
567	BM73108	VS THROTTLE LEVER
568	MP1356	FUEL SHUTOFF VALVE MTG
569	100099	Rectangular Ring Seal
570	100478	O ring seal
571	109686	Compression Spring
572	109687	Compression Spring
573	109688	Compression Spring
574	110855	fuel pump gasket
575	128807	Retaining Ring
576	129768	spring
577	129888	Rectangular Seal

578	138769	Compression Spring
579	138783	Compression Spring
580	138784	Compression Spring
581	138785	Compression Spring
582	138789	Compression Spring
583	138790	Compression Spring
584	138791	Compression Spring
585	138802	Compression Spring
586	138810	spring
587	138995	Compression Spring
588	138998	spring
589	139584	Compression Spring
590	139586	Compression Spring
591	139587	Compression Spring
592	139988	Rectangular Seal
593	142697	Compression Spring
594	142698	Compression Spring
595	142701	Compression Spring
596	142702	Compression Spring
597	142703	Compression Spring
598	142704	Compression Spring
599	142870	Compression Spring
600	143250	Compression Spring
601	143251	Compression Spring
602	143252	Compression Spring
603	143253	Compression Spring
604	143254	Compression Spring
605	143847	Compression Spring
606	143848	Compression Spring
607	143854	Compression Spring
608	143855	Compression Spring
609	144195	Compression Spring
610	146437	governor weight
611	146483	filter screen
612	146484	filter screen
613	151900	Rectangular Seal
614	153235	Compression Spring
615	153236	Compression Spring
616	153238	Compression Spring
617	153240	spring
618	154087	Rectangular Seal
619	154088	Rectangular Seal
620	160514	plain washer
621	163826	VS governor weight
622	166009	Compression Spring

623	179816	AFC spring
624	179818	AFC spring
625	179820	AFC spring
626	179822	AFC spring
627	179824	AFC spring
628	179828	AFC spring
629	179830	AFC spring
630	179832	AFC spring
631	179834	AFC spring
632	179836	AFC spring
633	193736	O ring seal
634	195265	pipe plug
635	196057	Valve Disc
636	202897	Fuel Pump Damper Diaphragm
637	205464	Compression Spring
638	212603	oil seal
639	213768	O ring seal
640	217631	pipe plug
641	3000592	AFC spring
642	3000933	spring
643	3000935	spring
644	3000936	Compression Spring
645	3000940	Compression Spring
646	3001146	Compression Spring
647	3001147	Compression Spring
648	3001148	Compression Spring
649	3001149	Compression Spring
650	3001155	Compression Spring
651	3001158	Compression Spring
652	3002047	Compression Spring
653	3002054	Compression Spring
654	3002056	Compression Spring
655	3002058	Compression Spring
656	3004750	Compression Spring
657	3008706	filter screen
658	3010510	O ring seal
659	3010945	dust seal
660	3013811	AFC diaphragm
661	3014010	shutoff valve body
662	3018767	Compression Spring
663	3021123	O ring seal
664	3021590	spring
665	3023478	Compression Spring
666	3025459	pipe plug
667	3030970	Valve Disc

668	3033740	check valve
669	3034167	Compression Spring
670	3034412	O ring seal
671	3034452	Actuator Disc
672	3040817	O ring seal
673	3042427	spring
674	3042428	spring
675	3042542	O ring seal145505
676	3044942	O ring seal
677	3044994	Threaded Plug
678	3044996	Threaded Plug
679	3044997	Threaded Plug
680	3044999	Threaded Plug
681	3045002	Threaded Plug
682	3045003	Threaded Plug
683	3045005	Threaded Plug
684	3045047	Threaded Plug
685	3045986	O ring seal 70775
686	3046201	O ring seal
687	3048182	O ring seal
688	3050624	Pressure Regulator Valve
689	3051071	AFC Compression Spring
690	3051461	lock nut
691	3051814	spring
692	3051817	spring
693	3051818	Compression Spring
694	3052231	Injector Link Retainer
695	3053156	spring
696	3053163	Compression Spring
697	3053164	Compression Spring
698	3053167	Compression Spring
699	3053170	spring
700	3054852	Compression Spring
701	3054999	filter screen
702	3060614	Compression Spring
703	3060615	Compression Spring
704	3062009	Injector Plunger Link
705	3062676	oil seal3045173
706	3066914	O ring seal
707	3069015	lock nut
708	3071704	spring
709	3071947	spring
710	3071951	AFC Compression Spring
711	3071951	spring
712	3074257	Orifice Plug

713	3075523	oil seal
714	3083834	sealing washer
715	3085343	spring
716	3088981	Threaded Plug
717	3088982	O ring seal
718	3090769	filter screen
719	3279794	O ring seal
720	3279819	conneting rod
721	3347937	O ring seal
722	68061	O ring seal
723	70415	O ring seal
724	70778	Compression Spring
725	70821	Compression Spring
726	70834	Threaded Plug
727	S16240	Retaining Ring
728	100129	Socket Head Capscrew
729	100764	fuel pump gasket
730	101841	shim
731	101842	shim
732	101843	shim
733	103089	plain washer
734	105375	nameplate
735	108384	Spring Pack Sleeve
736	109917	Socket Head Capscrew
737	110058	lock nut
738	112076	pipe plug
739	112408	plain washer
740	113244	idler gear
741	116935	Male Connector
742	116936	Male Adapter Elbow
743	118226	Socket Head Capscrew
744	118227	Ring Dowel
745	119363	Fuel Pumping Gear
746	119364	Fuel Pumping Gear
747	129838	knob
748	129839	shield
749	135169	Retaining Ring
750	144179	shim
751	153336	Fuel Pump Damper Body
752	153338	Fuel Pump Damper Cover
753	153346	Socket Head Cap Screw
754	153927	Socket Head Cap Screw
755	157088	Fuel Pump Filter Cap
756	163944	bushing
757	163945	Retaining Ring

758	167157	check ball
759	170942	Fuel Pumping Gear
760	173086	Threaded Plug gasket
761	173709	
762	173717	torsion spring
763	174299	Retaining Ring
764	174348	
765	175864	fuel pump shaft
766	175865	fuel pump shaft
767	177999	pipe plug
768	179068	shim
769	181213	Male Adapter Elbow
770	181466	lock washer
771	187556	screw
772	189800	shim
773	195755	Socket Set Screw
775	200635	pipe plug
776	200998	fuel pump gasket
777	201007	pipe plug
778	201008	idler shaft
779	201010	bushing
780	201745	loch washer
781	202897	Fuel Pump Damper Diaphragm
782	203346	Mounting Spacer
783	203426	roll pin
784	203848	Male Union
785	211636	governor gear
786	212602	Tachometer Drive Gear
787	212604	Retaining Ring
788	212605	fuel pump gear
789	212610	Tachometer Drive Gear
790	212668	Drive Gear Key
791	212954	Injector Stop Screw
792	213769	ball plug
793	214139	ball plug
794	214144	Needle AFC Valve
795	214150	plain washer
796	3000438	Retainer Plug
797	3000446	Fuel Control Cover
798	3000465	lock nut
799	3001707	AFC shim
800	3002110	male connector
801	3003156	Wire Seal
802	3004293	Retainer Plug
803	3004724	Seal Spacer

804	3004904	cover plate
805	3006344	Socket Set Screw
806	3010941	bushing
807	3012558	Fillister Head Cap Screw
808	3013810	AFC piston
809	3015226	VS Governor Housing
810	3015253	VS Governor Housing
811	3015469	Injector Spring Retainer
812	3015520	AFC fuel control cover
813	3018047	Fillister Head Cap Screw
814	3018682A	Fillister Head Cap Screw
815	3018682B	nylon pad
816	3020850	Female Connector
817	3021448	thrust bearing
818	3023088	Mounting Spacer
819	3023171	AFC piston insert
820	3025458	pipe plug 70295
821	3026163	fuel pump gasket
822	3028064	Cover Plate Gasket
823	3028088	Mounting Spacer
824	3030863	Female Connector
825	3033719	Ring Dowel
826	3033742	Threaded plug
827	3035230	Thrust Bearing
828	3040816	Threaded Plug
829	3046407	Socket Set Screw
830	3047278	AFC piston
831	3048557	Bearing Spacer(144302)
832	3051463	plain washer
833	3052860	Bearing Spacer
834	3053805	fuel pump gasket
835	3058868	Protective Cover
836	3063052	fuel pump gasket
837	3063056	Mounting Spacer
838	3065376	Spring Pack Cover(44678)
839	3065382	Threaded Plug
840	3079584	Threaded Plug
841	3096077	fuel pump gasket
842	3100517	Male Union(203850)
843	3175847	Male Union
844	3275156	spring washer
845	3419408	O ring seal
846	43765	Male Adapter Elbow
847	64816A	Pin Dowel
848	650036	Throttle Lever Stop

849	651109	Protective Cover
850	67684	plain washer
851	68138	male connector
852	68606	pipe plug
853	6899001	seal kit
854	6913001	spring
855	70700	spring
856	70704	plain washer
857	70705	Flange Gasket
858	70713	spring retainer
859	70715	plain washer
860	70716	Knurled Screw
861	70717B	Fuel Pump Governor shim
862	70760	Pin Dowel
863	70772A	Fillister Head Cap Screw
864	70772B	Fillister Head Cap Screw
865	70790	Socket Head Capscrew
866	70791	Socket Head Capscrew
867	70811B	shim
868	70813	Socket Set Screw
869	70823	Retaining Ring
870	70836	Throttle Lever Plunger
890	GB/T 860 8	Curved spring washers
891	S1028	Male Adapter Elbow
892	S1097	male connector
893	S110	Hexagon Head Cap Screw
894	S159B	Socket Head Cap screw
895	S168C	Hexagon Head Cap Screw
896	S174C	Socket Head Cap screw
897	S188C	Hexagon Head Cap Screw
898	S189C	Socket Head Cap screw
899	S213A	Regular Hexagon Nut
900	S2286 (repair)	Drive Screw
901	S248	Regular Hexagon Nut
902	S251	Regular Hexagon Nut
903	S270	Regular Hexagon Nut
904	S606	lock washer
905	137370	Idle Spring Plunger
906	140418	Idle Spring Plunger
907	140922-7	Idle Spring Plunger
908	141623-9	Idle Spring Plunger
909	141630-8	Idle Spring Plunger
910	144178	Gov Wgt Assist Plunger
911	145951	Idle Spring Plunger
912	212350	VS Governor Plunger

913	213610	VS Governor Plunger
914	3009380	Governor Plunger
915	3017140	Throttle Shaft
916	3018640	VS Governor Plunger
917	3036903	AFC Barrel/plunger Assembly
918	3040750	Governor Plunger
919	3046680	Throttle Shaft
920	3046690	Throttle Shaft
921	70820	vsIdle Spring Plunger
922	100133	fuel pump shaft
923	100215	Fuel Pump Drive Shaft
924	100216	Fuel Pump Drive Shaft
925	100217	Fuel Pump Drive Shaft
926	129826	shutoff valve body
927	175865	fuel pump shaft
928	175866	fuel pump shaft
929	185138	Injector Cup Retainer
930	185139	Injector Adapter
931	191916	conneting rod
932	205462	conneting rod
933	205463	Injector Adapter
934	207245	Injector Cup Retainer
935	211633	Governor Shaft
936	211635	Governor Pin
937	212601	Fuel Pump Drive Shaft
938	212607	Tachometer Drive Shaft
939	212609	Tachometer Drive bushing
940	212613	Jaw Coupling Hub
941	212639	Spline Adapter
942	3000266	Shutoff Valve Shaft
943	3000464	Injector Adapter
944	3006343	Throttle Lever Stop
945	3006550	Governor Carrier
946	3010942	Throttle Shaft
947	3010943	Throttle Shaft
948	3013036	Shutoff Valve Shaft
949	3014010	shutoff valve body
950	3014575	Fuel Pump Filter Cap
951	3021591	Throttle Lever Plunger
952	3023447	Fuel Pump Cover(3079939)
953	3023451	Fuel Pump Cover(big)
954	3023934	injector adapter(STC)
955	3027633	thrust bearing
956	3028302	Fuel Pump Cover(small)
957	3033730	Housing & Cover Assy

958	3033732	Gear Fuel Pump
-----	---------	----------------

959	3033734	Gear Fuel Pump
960	3033736	Gear Fuel Pump
961	3033738	Gear Fuel Pump
962	3033739	Fuel Pump Gear Cover
963	3034451	Actuator Housing
964	3036472	Idle Spring Plunger Guide
965	3036473	Idle Spring Plunger Guide
966	3036474	Idle Spring Plunger Guide
967	3041493	plain washer
968	3042425	injector adapter
969	3042430	Injector Cup Retainer
970	3047276	AFC piston
971	3049041	retainer spring
972	3052218	Injector Spring Retainer
973	3052233	conneting rod
974	3054292	Fuel Pump Cover3075525
975	3054345	Cover And Bushing
976	3054474	conneting rod
977	3055742	Injector Stop Screw
978	3058867	AFC cover
979	3062009	Injector Plunger Link
980	3064881	Injector Adapter
981	3066693	Injector Cup Retainer
982	3066707	Injector Spring Retainer
983	3068088	plain washer
984	3068859	Tappet Top Stop Cap
985	3068860	lock nut
986	3070155	Injector Plunger Link
987	3074256	Tappet Top Stop Lock Nut
988	3075524	Fuel Pump Cover(small)
989	3075525	Fuel Pump Cover(big)
990	3076040	Fuel Pump Adjusting Screw 3006175
991	3078200	lock nut
992	3090770	filter housing
993	3090771	filter housing
994	3090906	Fuel Pump Cover(small)
995	3279821	Injector Stop Screw
996	3279850	Tappet Top Stop Lock Nut
997	3411695	Injector Clamp
998	3419430	
999	3627894	Injector Plunger Link
1000	70690	Governor Plunger Driver
1001	70798	spring guide
1002	3034452	Actuator Disc