

CO2 Cylinder



TPK-00 (Non-Threaded)	Cu'ft:
30 pcs/ box	N.W.:
12 boxes/ CTN.	G.W.:
Non-Threaded	
CO2 Cylinder 12g	
/ 30pcs/ box	



TPK-00A (Threaded)	Cu'ft:
30 pcs/ box	N.W.:
12 boxes/ CTN.	G.W.:
Threaded	
CO2 Cylinder 12g	
/ 30pcs/ box	



TPK-01 (no sticker)	Cu'ft: 0.8'
TPK-01A (sticker)	N.W.: 22kgs
30 pcs/ box	G.W.: 23kgs
12 boxes/ CTN.	
CO2 Cylinder 16g	
/ 30pcs/ box	



TPK-08 (no sticker)	Cu'ft: 0.6'
TPK-08A (sticker)	N.W.: 17kgs
20 pcs/ box	G.W.: 18kgs
8 boxes/ CTN.	
CO2 Cylinder 25g	
/ 20pcs/ box	




TPK-02	Cu'ft: 0.55'
2 pcs/ box	N.W.: 13kgs
100 boxes/ CTN.	G.W.: 14kgs
CO2 Cylinder 16g/ 2pcs	




TPK-03	Cu'ft: 1'
2 pcs/ box	N.W.: 29kgs
140 boxes/ CTN.	G.W.: 30kgs
CO2 Cylinder 25g/ 2pcs	

Usage



Connect the tire & pipe



Prick & fasten the valve directly

Tire Repair Tools (Car & Motor)

TPK-04 (16g)

Cu'ft:
N.W.:
G.W.:

2 pcs/ bag
5 bags/ inner box
30 inner boxes/ CTN.

CO2 Cylinder 16g/ 2pcs



TPK-05 (25g)

Cu'ft:
N.W.:
G.W.:

2 pcs/ bag
5 bags/ inner box
20 inner boxes/ CTN.

CO2 Cylinder 25g/ 2pcs



TPK-06 (16g)

Cu'ft: 0.74'
N.W.: 12kgs
G.W.: 13kgs

40bag/ CTN.

CO2 Cylinder 16g/ 5pcs



TPK-06A (16g)

Cu'ft:
N.W.:
G.W.:

box/ CTN.

CO2 Cylinder 16g/ 5pcs



TPK-07 (25g)

Cu'ft: 0.74'
N.W.: 15.5kgs
G.W.: 16.5kgs

32bag/ CTN.

CO2 Cylinder 25g/ 5pcs



TPK-07A (25g)

Cu'ft:
N.W.:
G.W.:

box/ CTN.

CO2 Cylinder 25g/ 5pcs



TPK-54 (16g)

Cu'ft:
N.W.: 23.4kgs
G.W.: 24.4kgs

10 sets
/ inner box
12 inner boxes/ CTN.

CO2 Cylinder 16g/ 3pcs
CO2 Cylinder cover/ 1pc



TPK-55 (16g)

Cu'ft:
N.W.:
G.W.:

10 sets/ inner box
12 inner boxes
/ CTN.

CO2 Cylinder 16g/ 2pcs
CO2 Cylinder cover/ 1pc
CO2 Connection pipe/ 1pc
Plastic adapter/ 1pc



TPK-64 (16g)

Cu'ft: 2.2'
N.W.: 27 kgs
G.W.: 28 kgs

10 sets/ inner box
10 inner boxes
/ CTN.

CO2 Cylinder 16g/ 4pcs
CO2 Cylinder cover/ 1pc



TPK-64A (16g)

Cu'ft: 2.2'
N.W.: 27 kgs
G.W.: 28 kgs

boxes/ CTN.

CO2 Cylinder 16g/ 4pcs
CO2 Cylinder cover/ 1pc

