

FT120/FT121/FT1200 Series

Introduction:

Rated current: 0.5A~1600A

Optional medical versions (H type)

Various terminals: wire, solder lug, stud,

terminal blocks, etc

Custom specific versions available on request



Features and Benefits:

-- High performance AC filters with exceptional common and differential mode filtering effect for interference from 10KHz to 30MHz.

-- FT120 and FT121 series are two-stage common mode filters with almost the same filtering effect, only slight difference according to different current.

-- FT1200 series are two-stage filters comprising one common mode and one differential mode with enhanced filtering effect of the differential mode interference.

-- High voltage versions above 380VAC are also available.

Typical Applications:

Electrical and electronic equipment

Consumer goods

Household appliance

Medical device




Office automation equipment

Datacom equipment

All kinds of power supplies and other noisy applications requiring high filter performance






Electrical Schematics:



Technical Data:


Rated Voltage: V_R	110/250VAC
Operating Frequency: f_R	50/60Hz
Rated Current: I_R	0.5~1600A@40°C
Test Voltage: V_{test}	1760VDC, 3S(line-line); 2000VAC, 3S(line-ground)
Climatic Category(IEC 60068-1)	25/085/21(-25°C/+85°C Damp heat test for 21 days)

Tabulates:


Part No.	Rated Current [A]	Leakage Current [mA] 250VAC/50Hz @20°C	Terminals			Weight [g]
						
			-S	-L	-W	
FT120-1	1	<0.5	---	---	○	95
FT120-3	3	<0.5	---	---	○	95
FT120-6	6	<0.5	---	---	○	95
FT120-10	10	<1.0	---	○	---	170
FT121-3	3	<0.5	---	○	---	170
FT121-6	6	<1.0	M4	○	---	170
FT121-10	10	<1.0	M4	○	---	170
FT121-20	20	<1.0	M4	○	---	320
FT121-30	30	<1.0	M6	---	---	320
FT121-50	50	<2.0	M6	---	---	1400
FT121-60	60	<2.0	M6	---	---	1400
FT121-80	80	<2.0	M8	---	---	2000
FT121-100	100	<2.0	M8	---	---	2000
FT121-150	150	<2.0	M10	---	---	3000
FT121-200	200	<2.0	M10	---	---	3000
FT1200-1	1	<0.5	---	---	○	65
FT1200-3	3	<0.5	---	---	○	95
FT1200-6	6	<1.0	M4	○	---	175
FT1200-10	10	<1.0	M4	○	---	175
FT1200-20	20	<1.0	M4	---	---	600
FT1200-30	30	<1.0	M6	---	---	600
FT1200-50	50	<2.0	M6	---	---	1600
FT1200-60	60	<2.0	M6	---	---	1600
FT1200-80	80	<2.0	M8	---	---	2000

Insertion Loss(dB):


—— common mode - - - - differential mode




FT120-1 FT120-3




FT120-6 FT120-10




FT121-3 FT121-6




FT121-10 FT121-20




FT121-30 FT121-50




FT121-60 FT121-80




FT121-100




FT121-150




FT121-200




FT1200-1 FT1200-3




FT1200-6 FT1200-10



FT1200-20 FT1200-30




FT1200-50 FT1200-60




FT1200-80

Note: Insertion loss is tested with a system of empty load and 50Ω-50Ω according to UL1283 Standard. The actual effect please follow the field data of real application.

FT121-20/30




FT121-50/60/80/100/150/200




FT121-20~200

	20A	30A	50A	60A	80A	100A	150A	200A	TOL
A	73	73	150	150	200	200	200	200	±1
B	56	56	105	105	127	127	127	127	±1
C	45	45	60	60	80	80	80	80	±1
D	97	97	---	---	---	---	---	---	±1
E	---	---	135	135	170	170	170	170	±1
F	105	114	190	190	264	264	263	263	±1
G	87	87	90	90	116	116	116	116	±1
H	---	---	120	120	150	150	150	150	±1
I	Φ4.8	Φ4.8	Φ4.0	Φ4.0	Φ6.0	Φ6.0	Φ6.0	Φ6.0	±0.5
J	---	---	6	6	9	9	9	9	±0.5
K	24	24	50	50	70	70	70	70	±0.5
L	28.5	28.5	35	35	50	50	50	50	±0.5
M	12	12	15	15	30	30	30	30	±0.5
N	3.3	3.6	3.1	3.1	9	9	4.4	4.4	±0.5
Q	M4	M6	M6	M6	M8	M8	M10	M10	---

FT1200-20/30



FT1200-50/60/80



FT1200-20~80

	20A	30A	50A	60A	80A	TOL
A	96	96	150	150	200	±1
B	80	80	105	105	127	±1
C	42	42	60	60	80	±1
D	---	---	---	---	---	±1
E	105	137	135	135	170	±1
F	128	128	190	190	264	±1
G	50	50	90	90	116	±1
H	95	95	120	120	150	±1
I	Φ4.0	Φ4.0	Φ4.0	Φ4.0	Φ6.0	±0.5
J	6	6	6	6	9	±0.5
K	42	42	50	50	70	±0.5
L	20	20	35	35	50	±0.5
M	20	20	15	15	30	±0.5
N	3.3	3.6	3.1	3.1	9	±0.5
Q	M4	M6	M6	M6	M8	---


Important Notes on EMI Filter Application:

I . Storage of EMI Filters:

EMI filters mustn't be left out in the heat of the sun or exposed to the rain, it should be stored in warehouse with good ventilation, surrounding temperature between -30°C and $+65^{\circ}\text{C}$, the highest relative air humidity lower than 90%, and no corrosive liquid or gas.


II . Installation of EMI Filters:

- EMI filters should be installed at power input, and the line inside the chassis be as short as possible to reduce radiated interference.
- Both input and output lines of EMI filters neither be intersected nor be tied up by string.
- Make sure the mounting flange fully grounded, and keep the ground cable as short as possible if filters are connected to other equipment.
- If the terminal is stud, please use two spanners to fasten the screw nut when connecting to avoid stud rotating and thus causing changes to the internal circuit and consequently leading to filters arcing, short circuit, broken down or the filtering effect worsened. First use spanner1 to fix the screw nut near the metal case, then use spanner2 to tighten the screw nut in front(shown as Figure1), otherwise the terminals may be damaged. Apply the same for the connection of other phases.




(Figure1)

- Keep the tools fastening the stud be vertical to the metal case of filter when installing terminal block filters(shown as Figure2), must not tilt(shown as Figure3), otherwise the terminal blocks may be damaged.



(Figure2)



(Figure3)

III. Reminding and Warning:

Please read all the safety warnings and instructions before installing filters and putting them into use:

- Don't take terminals as supporting point when moving filters to avoid the terminals distortion, loosening or broken.
- The protective earth connections shall be the first to be made when the EMC filter is installed and the last to be disconnected.
- Filters generate leakage current, please make sure they are well grounded before put into operation.
- If the rated current is higher than 50A, we recommend grounding by the earth terminals but not only through the metal case of filters.
- Danger of electric shock: EMC filters contain components that store an electric charge. Dangerous voltages can continue to exist at the filter terminals for longer than five minutes even after the power has been switched off.
- The working conditions of EMI filter should comply with the technical parameters stated on the label, over voltage or overload could cause damage to filters. It is suggested to take proper over current protection measures.
- Current drop occurs when the surrounding temperature rise, fail to follow the current drop requirement may lead to impermissible exceeding of the component temperature, as a result the service life of filters will be shortened after long time running.



Service and Support:

Contact information of Tech. Dept.:

T: 0086-531-58622887
F: 0086-531-58622899
E: filtemc@filtemc.com
A: Building 20, Xinmao Qilu Science and
Technology City, No. 1 Zidong Road, Tianqiao
District, Jinan 250119, China

Contact information of Sales:

T: 0086-531-58622885
F: 0086-531-58622886
E: filter@filtemc.com
Skype: Lisawong2016@hotmail.com
Web.: www.filtemc.com