SPECIFICATIONS SHEET FOR THE WW-EG01

WW-EG01 with 15°, 25°, 30° and 60°

LED and Driver Module
Unscrew to replace the LED and Driver

WW-EG01 with 150°

LED and Driver Module
Unscrew to replace LED
Unscrew to replace drive

SPECIFICATIONS:

Fixture: Flood Light
Mode: WW-EG01
Beam Spread: 15˚ 25˚ 30˚ 150˚, CLE/Frosted Glas s
Color Temp.: 2700K/3000K
Type: Low voltage LED
Operating Voltage: 9V - 16V
Wattage: 2W(min)   - 7W(max)
Lumen Output: 160LM - 600LM

The silicone plug
Dip swatch

Function Description：

1. WW-EG01 can be used as floodlight or spot light；
2. Power switch from 2W-7W；
3. Replace optics to change beam angle；
4. Easy replace light source ＆ driver module.

Structure：

1. Use raw copper for production；
2. Water/dust proof, protect insects get inside；
3. Use high borosilicate glass with high transmittance；
4. All electronic drivers comply with US and Canadian electrical codes.
5. All connections are with the waterproof wire nuts.

Safety Instructions：

Turn power OFF or unplug fixture and allow it to cool before replacing lamp.

Lamp gets HOT quickly. Contact only switch/plug when turning on.

Do not touch hot lens, guard, or fixture housing until it has cooled.

Keep lamp away from combustibles.

The inner module is hot, don't touch it until it gets cold.

Do not operate the fixture fitting with a missing or damaged shield.

For outdoor use only.

Make sure the power is turned OFF before installing or servicing this fixture.

Installation Instruction：

1．Disconnect the transformer from the main supply；
2．Plug the cable through the stake and connect to the main cable.

Module Replacement Instructions：

Unscrew the front cover, take out the glass, loosen the screws from the aluminum plate to remove the module.

WARNING:

Risk of electrical shock. Install all fixture 10 feet (3.05m) or more from a pool,spa,or fountain.

This fixture is to be used with a low voltage power supply that does not exceed 15V.

The copyright of the eagle logo on the lamp body belongs to LED Story.