

TH118

Product feature TH118 is developed to be suited for high speed tissue head pick up. It has long open time, dry film flexibility, excellent balance between wet tack and dry peel strength which are very suitable for soft tissue manufacturing. Dependent on different type of machine and substrate, it's was suggested that you dilute TH118 with water with recommended ratio from 1:2 to 1:7(TH118:water).

Apply process Spraying process and roller system were recommended to apply this adhesive.
Wash machine and tools with water.

Laws and regulations All materials shall comply with the FDA (us food and drug association) rule 21 CFR 175.105 "adhesive".

Physical parameters

- **Appearance** Milky White to Light Yellow Translucent Liquid
- **Solid Content** 18.0 – 26.0 Bx
- **Viscosity** 30,000 — 70,000 cps (Brookfield/6#/6rpm/27°C)

Packaging 20 kg/drum,50 kg/drum

Storage conditions Store in a dry place where the temperature is over 6 °C and the storage life is six months.

- Cautions**
- Forbidden to mix with other products.
 - Store in closed containers to prevent drying out and contamination.
 - Rotate stock - first in, first out.

Review:2021-08-01/Kelly Wang●

Hetrun Industry Group Limited●

Guangzhou office

Banqiao road 20#,Nancun,Guangzhou

Tel : 020-39116768

fax : 020-39111477

Email : Service@hetrun.com

Beijing Office

Qinniangu Road 4#,Esatcity,Beijing

Tel : 010-64216206

fax : 010-64216206

Email : Service@hetrun.com

Hubei office

Miaoshan district, Jiangxia, Wuhan, Hubei

Tel : 18928952934

Email:Service@hetrun.com

Because we do not know all the production process and the potential user demands, so this data sheet is for reference only, and cannot fully guarantee the product compatibility and applicability